

Farmcomp Oy
RM, AJ, LP
16.2.2010



Hay and straw moisture meter update.

English translation original and translations to Finnish, Swedish and Russian from Farmcomp.

EN English

QUICK INSTRUCTIONS Hay, Straw, Silage Moisture Meter

1. Push the probe into the bale
2. Switch on the meter by pressing the ON
3. Select the scale with MENU. Use the hay scale for silage.

Round bales	Hay	-1-	Straw	-4-
Big square bales	Hay	-2-	Straw	-5-
Small rectangular bales	Hay	-3- ***	Straw	-6- ***

*** Select bale density from 80 to 250 kg/m³ - For small bales you can usually use 180 kg/m³.
4. The display will show "run", after a few seconds the moisture per cent will be displayed. Finally the meter switches itself off automatically and is ready for a new measurement.

CS Czech

STRUČNÉ POKYNY pro měřič vlhkosti sena, slámy a siláže

1. Zatlačte sondu do balíku
2. Zapněte měřič stiskem tlačítka ON
3. Pomocí tlačítka MENU vyberte měřítko. Pro siláž použijte měřítko pro seno (Hay).

Kulaté balíky	Hay (Seno)	-1-	Straw (Sláma)	-4-
Velké čtvercové balíky	Hay (Seno)	-2-	Straw (Sláma)	-5-
Malé čtvercové balíky	Hay (Seno)	-3- ***	Straw (Sláma)	-6- ***

*** Vyberte hustotu balíku od 80 do 250 kg/m³ – U malých balíků lze obvykle použít 180 kg/m³.
4. Na displeji se zobrazí zpráva „run“ (chod), po několika sekundách se zobrazí procento vlhkosti.
Nakonec se měřič automaticky vypne a je připraven na nové měření.

www.ohaus-vahy.cz www.vahy-mb.cz www.metroservis.cz

info@metroservis.cz



Dodavatel:
Metroservis s.r.o. Kladenská 6 Hostouň 27353